


T : 020 8953 6177 • MarkhamClose E: enquiries@arbourlandscapesolutions.co.uk www.arbourlandscapesolutions.co.uk

## **External Stepped Panel Joint**

To produce an external joint on a stepped panel you will need to butt the two pieces together standing up on a flat surface.






Next you will need to mark the rear of the panels for where you need to cut.



Where to cut on the rear of the panel; note the different pencil marks on the separate strips as each strip is cut separately.



Finished article after raw cutting.



